






MinumOSD Connection to AQ M4V2




This jumper will prevent burning out MinumOSD if to much Current tries to flow through it's small ground trace



Vid Out
+12
Gnd



Voltage to ADC input



5 volt power from MinumOSD
Use on M4V2 only

